

## Instructions for your compost toilet

- \* Place the toilet on a base of newspaper, cardboard or similar. The tub is **only** designed as a latrine, and not for dishwasher, rubbish, sanitary pads or other items.
- \* Before use, strew a thin layer (about 2 cm) of our *TOA Skogsströ* sawdust to cover the bottom of the tub.
- \* Add a small amount of *TOA Skogsströ* sawdust at regular intervals so that the compost in the toilet maintains a porous structure and correct moistness. If the mass becomes too fluid, add a little more *TOA Skogsströ*. Should the mass become dry, it may start to smell. In such case, add a little water.
- \* When the toilet is full, remove the seat and put on the accompanying lid. Take a new tub, assemble the seat, and strew a thin layer of *TOA Skogsströ* sawdust to cover the bottom of the tub.
- \* The tub should be placed in the **hallway** after changing, and all related materials should be placed together so that we can assess your requirements. **Tubs should never be placed in the staircase**, with consideration to your neighbours and risk of fire.
- \* Tubs are changed once a week as required or as instructed.

The toilet is put in place.

Cover the bottom with a 2 cm layer of sawdust.

Add about 1 dl of sawdust after each use.

The tub is changed/collected once a week or as instructed.

Planting soil is obtained after composting.



The toilet is composed of only natural and primary materials, and is subsequently fully recycled. The appliance is particularly useful when undertaking major plumbing work or bathroom refurbishments or similar projects.

Skogstoan AB is environmentally certified as per ISO 14001 and quality certified as per ISO 9001.

Skogstoan AB  
Krossgatan 29  
162 50 VÄLLINGBY

Tel: +46 (0)8-37 92 48  
[www.skogstoan.se](http://www.skogstoan.se)  
[info@skogstoan.se](mailto:info@skogstoan.se)